

IMPORTANT TIPS

ALWAYS test the paint on one piece first before applying paint to multiple pieces.

Use a slightly wet brush for all steps unless otherwise specified for a drybrush technique.

IF YOU MAKE A MISTAKE

If the paint is still wet, quickly wash the paint off with soap and water, dry the piece and start again.

If the paint has dried but not cured, remove the paint with a kitchen scrubber or brush and soap and water. This might be difficult if the paint has gotten into the deeper areas of the piece, so we suggest priming the piece with *Base Gray* (or *Base Gray* mixed with a small amount of Black to match the original color of the *Dwarvenite*).

If the paint has cured, it must be primed before repainting. We suggest priming the piece with *Base Gray* (or *Base Gray* mixed with a small amount of Black to match the original color of the *Dwarvenite*).

COLOR MIXING*



^{*} Please use discretion and test all colors first.